



Dear Revox Partner,

We would like to inform you about the upcoming software update for the **STUDIOCONTROL C200**. The update, which will be available from tomorrow, contains important adjustments and enhancements. We would also like to introduce you to Jeremy Mörbt, another contact person in our Revox Support. Read all the details in this newsletter.

We wish you continued good business with Revox products.

Your  
Revox Team

---

## **New STUDIOCONTROL C200 Update**

A new software update with version C200 V1.1 (20240606) will be available from Tuesday, July 2. The update will be installed automatically on the **STUDIOCONTROL C200** as long as the battery level is high enough and there is an Internet connection. We therefore recommend placing the **STUDIOCONTROL C200** in the docking station overnight so that the update is installed the next morning. After the update, an update message appears on the display with the current version information. As soon as this message is acknowledged, the C200 can continue to be used as usual. Please do not forget to check the start screen and rearrange the apps if necessary (see note on start screen).

### **Optimized charging behaviour**

The previous charging behavior had a charging cycle that was too short. This meant that the built-in battery was recharged at too short an interval after it was 100% charged and could therefore be damaged. Furthermore, this fast recurring charging cycle could cause the **STUDIOCONTROL C200** to restart automatically. Both potential sources of error have now been eliminated by the adjusted charging behavior. The C200 is now charged to 100% and then drops to 90% before recharging begins.

### **Multiusers 3 and STUDIOART app included**

All Revox apps are now pre-installed in the new version V1.1(20240606). Multiusers 3 and the **STUDIOART** app have been added and the existing C200 apps have been updated to the latest version. The two additional Revox apps create a new arrangement on the start screen. Please read the information on the home screen below.

### **Wake up display by touch or volume button**

There is a new touch & volume to wake function that can be used to wake the display from standby. The C200 can be woken up from standby by pressing one of the two volume buttons or by touching the display. Please note that the touch to wake function does not react when the C200 is in deep sleep mode. The time after which an Android device falls into deep sleep mode depends on the charge status and background activities. The C200 can therefore switch from standby to deep sleep within a period of 1 to 10 minutes.

### **These are further improvements**

- Background processes optimized, resulting in less processor load
- Battery optimization deactivated for all Revox apps, resulting in faster reconnection after standby
- Latest security packages Google/Android version 11
- WLAN connection behavior optimized during initial commissioning

## New start screen

We have decided to install the two new apps (Multiuser 3 and **STUDIOART**) directly on the home screen so that they are immediately visible. This results in the home screen being reset to the factory settings (see image).

After the update, an individual arrangement of the apps can be restored in a few simple steps. To do this, open the App folder by swiping up on the start screen and move your Apps to the desired location using drag&drop.

If you use the Revox **STUDIOCONTROL** launcher, you have even more advantages: the arrangement of the apps in the launcher is not affected by the update.

## Initial commissioning of the C200

The new software version is not yet installed ex works. The update will only be carried out after the C200 has been commissioned, when it is connected to the Internet and placed in the docking station. New **STUDIOCONTROL** C200s are supplied with an update notice in the packaging.



## New addition to Revox Support



We are very pleased to introduce Jeremy Mörbt as an additional colleague for our technical support. As a state-certified technician with a wealth of experience, Jeremy is ideally prepared for the challenges of the audio world and the smart home sector. He will be a great support and competent contact person for us and for you.

Jeremy Mörbt  
Tel: +49 7721 8704 33  
Mail: [support@revox.com](mailto:support@revox.com)



# REVOX

Studio Sound Quality

Revox (Schweiz) AG  
Eichwatt 5  
CH 8105 Watt-Regensdorf

Revox Deutschland GmbH  
Am Krebsgraben 15  
D 78048 VS-Villingen

Revox Handels GmbH  
Josef-Pirchl-Strasse 38  
AT 6370 Kitzbühel

[Recommend newsletter](#) | [Unsubscribe](#) | [Imprint](#)